

CONNECTIONS

Supply voltage must be filtered DC of 10-35V, and ripple should be less than 30% at full load.
CAUTION ! Wrong polarity can damage the unit.
CAUTION ! Unit doesn't have an internal fuse, so an external fuse should be added if fuse required.

MONITORABLE VALUES

- 1/5 Motor current 0-20A (0-200)
- 2/5 PWM-level-% 0-100% (0-100)
- 3/5 hour counter (max.65535h)
- 4/5 start counter (max.65535)
- 5/5 carry counter for start counter

FAULT-LED signal codes


- 1. power on one blink
- 2. current on limit led is lit
- 3. current trip fast blinking...
- 4. zero-cur trip long blink- short pause...
- 5. overvoltage 4 x blink -pause...
- 6. overheat short blink- long pause...
- 7. timeout 3 x blink + long blink...
- 8. fault input 2 x short + 1x long blink...

ADJUSTMENT AND SETTINGS (prog ver. EM-324C v2.0)

Adjusting and parameter setting of eg. current limit value, ramp times and speed-2 value is done with the EM-236 interface unit.
 With EM-236 the parameters and adjusted values can also be copied to multiple devices accurately and reliably.

SETTABLE PARAMETERS 22pcs. (defaults in brackets)

- 1- command mode: 0,1 and 2 (0)
 - 0= continuous FW / REV
 - 1= impulse commands FW / REV. with stop
 - 2=impulse commands FW / REV without stop
- 2- start condition combinations: 0-3 (1)
 - 0= start both direction after I-trip and Stop
 - 1= start only opposite direction after I-trip
 - 2= start only opposite direction after Stop
 - 3= start only opposite direction after I- and Stop
- 3- input logic combinations 0-7 (0)
 - PNP control with positive signal and input has pull down res.
 - NPN control with negative signal and input has pull up res.
 - N.C. = input resistor as above, but control signal logic is inverted
 - 0= cont. PNP, limits PNP 4=cont. PNP, limits PNP N.C.
 - 1= cont. NPN, limits PNP 5=cont. NPN, limits PNP N.C.
 - 2= cont. PNP, limits NPN N.C. 6=cont. PNP, limits NPN
 - 3= cont. NPN, limits NPN N.C 7=cont. NPN, limits NPN
- 4- running speed-1: 0-100% / 0-100 (100)
- 5- running speed-2: 0-100% / 0-100 (50)
 - Note: If selected to 0 or 1 "speed2-input" is used as analog 0-5V speed control input, and when 1 is selected FW direction is automatically "on" and FWD input works as direction change
- 6- current limit FW: 0.1-5A / 1-50 (30)
- 7- current limit REV: 0.1-5A / 1-50 (30)
- 8- Trip combinations: 0-3 (1)
 - 0= no I-trip, no zero-current-trip
 - 1= only I-trip
 - 2= only zero-current-trip
 - 3= both I-trip and zero-current-trip
- 9- I-trip delay: 0-255ms / 0-255 (20)
- 10- Fault output combinations: 0-3 (1)
 - 0= I-trip and zero current won't cause fault output signal
 - 1= only I-trip causes fault output signal
 - 2= only zero current causes fault output signal
 - 3= both I-trip and zero current causes fault output signal.
 - 4= overcurrent indication
 - 5= "run" indication = pull down when motor run
- 11- overvoltage limit: 15-40V / 15-40 (35)
 - Overvoltage can be caused by load driving the motor or when braking the speed down but supply can not accept the current back from driver. Exceeding the limit will cause the power stage set to free-wheel state.
 - With a direct battery supply the brake current is charging the battery and the voltage will not normally rise.
 - There is also 40V fixed dynamic brake point = motor pole shorted
- 12- load compensation: 0-255 / 0-255 (0)
 - Load compensation (RxI) improves low speed and start torque, but too high compensation achieve unstable running.
 - Run motor at low speed (30%) Increase compensation with small steps until motor start behaviour unstable, then decrease value about 10%
- 13- timeout: 0-255s. / 0-255 (0=not in use) (0)
- 14- Reset for start and hour-counter 0/1 (0)
 - selecting 1 and push SAVE => reset counters
- 15- start ramp: 0-5s / 0-500 (100)
- 16- stop ramp: 0-5s / 0-500 (100)
- 17- start-kick 0-200ms / 0-200 (0)
 - This gives full drive at start and I-lim is 7A
 - The start kick length is 0-200ms.
- 18- I-trip auto reversing 0-5s / 0-500 (0)
 - Change automatically run direction when I-trip occurs the reversing time will select with this parameter
- 19- Freewheel options 0-5 (0)
 - 0= freewheeling when overvoltage
 - 1= freewheeling when overv. or stopped
 - 2= freewheeling when overv. or during stop ramp
 - 3= freewheeling when overv. or when stopped or during stop ramp
- 20-operating frequency 1=2kHz / 2=16kHz (1)
- 21 Serial port configuration, speed, parity, and number of stop bits (1)
 - 1 =9600bps 8N1 5 =19200bps 8N1
 - 2 =9600bps 8N2 6 =19200bps 8N2
 - 3 =9600bps 8E1 7 =19200bps 8E1
 - 4 =9600bps 8O1 8 =19200bps 8O1
- 22 Modbus address 1-247 (1)



Molex connectors (with dashed lines)
 6-pole 22-27-2061
 8-pole 22-27-2081